


MANUEL EN COURS DE TRADUCTION





MANUEL DE MONTAGE

Moto enfant ZR-1000 18W - Voiture KINGTOYS



- Adapté aux enfants de 3 à 8 ans
- Capacité maximum : 25kg
- Le montage doit être effectué par un adulte
 - Conserver ce manuel.

 Avant la première utilisation, charger la batterie durant 4-6 heures.

Table of Contents

1 Brief Instroduction And Models	01
2 Important Safety Instructions	02
3 Parts List	02
4 Parts Diagram	05
5 Assembly Steps	06
6 How To Operation Your Vehicle	09
7 Charging The Vehicle	1 C
8 Caring For Your Vehicle	1 C
9 Problems And Solutions Guide	1 C
10 Disposal Of Battery	12
11 Specail Explaination	12

Brief Instroduction And Models

Thank you for choosing our vehicle. Each vehicle pattern is designed upon a unique mold: such as the realistically imitated vehicle and cute series, which bring different fun and feeling for yourchildren.

We wish our vehicle to accompany your children for a happy childhood and your family will be filled with joy and happiness.

Age:	3-8 ans	Poids:	Max 25KGS
Speed:	3-4.5 KM/H	Size Of Car:	99*41*64.5CM
Charger:	Input: 220V 50Hz Input: DC6V 500ma Input: DC12V 700ma		6V-4.5Ah*1/2 6V-7Ah*1
Power Way:	Charging Type	Charging Time:	8-12 Hours
Fuse: 15A		Average Battery Life:	Approximately 300 Times


Read carefully and follow all the instructions

🗥 WARNING ! CAUTION

Assembly/Used



Product requires adult assembly. Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state.





Always properly handled the protective material and poly bags before assembly. Always properly namined the protective material and perfective find the problem of the problem o



Suitable for age months; Maximum user weight is 25 Kgs.



 $\underline{\text{1}}$ Choking hazard----small parts. This product is forbidden to children under 3 years.



Direct Adult Supervision Required. Never leave child unattended by himself. Always keep child in view when he is in vehicle. Teach appropriate safety rules to your child before allowing operation of this vehicle. These rules should also be reviewed with other playmates who want to drive this vehicle.


Make sure children know and follow these rules for safe driving and riding:

- Always wear shoes;
- Always sit on the seat;
- Always wear a helmet when riding;
- · Only one rider at a time.



Keep children within safe riding areas, these areas must be:

- A Away from steps/cars/driveways/roads and alleys;
- B Away from sloped/inclined surfaces/swimming pools or other bodies of water;
- C Away from other dangerous places;
- Only outdoors. Generally flat ground/playground /Garden asphalt and other





Before using, adult should check the main components whether in good condition:

Battery plug should been plugged in, power is switched; battery/charge/wire/plug/ car body and other parts whether is damage; whether screw loose; whether have another demage problems. To avoid using damaged car until it repaired.



To avoid demaging the motors and gears, stop the vehicle before shifting from forward to backward switch.

- Please turn forward/stop/backward switch to "O" in the state of no-driving. Turn off power switch.(notice:this switch only control the parts of drive.)
- Do not let any child touch the wheels or near them when the car is moving.
- This vehicle has adjustable play seat belts. Please instruct children how to tie the safety belt before using, guarantee the security.
- Do not tow anything behind the vehicle or overload it, do not exceed the maximum weight capacity of 25 kgs.

Battery / Charger / Alkaline Batteries

The battery/ charge/ alkaline batteries are not toy, strictly children play.

Non-rechargeable batteries are not to be recharged. Do not charge non-rechargeable batteries.

Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).

Battery charging must be done by adults only.

Remove rechargeable batteries from the vehicle before charging.

Insert batteries are correct polarity inside the battery compartment. (show picture)

Remove exhausted batteries from the product.

Remove batteries during long periods of non-use.

Never short-circuit the battery terminals.

D.C1.5V(SIZE:AA)

⚠ Use only with manufacturers prescribed rechargeable battery and charger.

DO NOT use the battery or charger for any other product. Could cause overheating, fire or explosion.

DO NOT open the battery and the charger.

DO NOT charge battery upside down.

Always maintain battery dry. Do not let the vehicle contact fresh water or salt water.

Charge

Charge 4-6 hours before the first time using, but not charge over 10 hours.
Only adult may handle or charge the battery. Never allow child to do that.
Turn off power switch before charge the battery.

When the vehicle's normal speed apparent slow down or after each use, recharge the battery for 8-12 hours, never charge the battery longer than 18 hours.

Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the charge or the battery until you have replaced the worn or damaged parts.

Charge the battery in a dry area ONLY.


It is normal that charger and battery are tepid while charging.


Charge the battery at least once per month, even if the vehicle has not been used.

In room temperature below 5 degrees centigrade, charging the actual to lengthen 3-5 hours. Below -5 Celsius please do not use this product.

Parts List

Please identify all parts before assembly and save all packaging materials until assembly is complete to ensure that no parts are discarded.






\bigcap	Vehicle Body	10	M4 [★] 22 Screw
2	Front Fender	11	Front Instrument Panel
3	Front Wheel	12	Screw
4	Gasket	13	Rearview Mirror
5	m10 Non-slip nuts	14	Windshield
6	Front Axle	15	
7	Front Axle Casing	16	
8	Auxiliary Wheel	17	
9	${\mathcal M}4$ Non-slip nuts	18	

Étapes de montage


Note:

Lors du montage des roues sur les essieux, il faut procéder à l'étanchéité des deux joints. Vérifier s'il faut ou non augmenter les joints pour ajuster le degré d'étanchéité des roues



Montage des roues auxiliaires


- Visser les roues auxiliaires à travers la roue arrière.
- Fixer les roues auxiliaires au véhicule en utilisant un écrou antidérapant M5*22mm.



Montage de la fourche avant


- Mettre l'aile avant dans la position de la fourche du véhicule.
- Utiliser deux vis 4*12mm pour fixer la fourche et la carrosserie du véhicule ensemble.

Étapes de montage




Montage de la roue avant

- Monter l'essieu avant par la côté gauche de la fourche.
- Ajouter un carter d'essieu avant à l'essieu avant.
- Glisser la roue avant sur l'essieu.
- Ajouter l'autre boîtier de l'essieu avant de l'autre côté.
- Glisser l'essieu avant par le côté droit de la fourche avant.
- Ajouter un joint d'étanchéité sur les deux côtés de l'essieu avant, puis utiliser la vis pour serrer.



Montage du tableau de bord


- Raccorder la lumière sur le tableau de bord avant et le connecteur de la fourche du véhicule.
- Utiliser 4 vis 4*12mm pour connecter le tableau de bord avant et la carrosserie.



Montage du pare-brise


Placer convenablement le pare-brise dans son emplacement.
 Utiliser 2 vis 3*12mm pour brancher le pare-brise et la tête.

Étapes de montage




Montage des rétroviseurs

 Placer les rétroviseurs à leurs emplacements respectifs.
 Utiliser 2 vis 4*12mm pour fixer le tableau de bord avant et les retroviseurs.




Connexion de la batterie

 Insérer le fil rouge dans la colonne rouge (ne pas insérer dans la colonne noire).
 Insérer le fil noir dans la colonne noire (ne pas insérer dans la colonne rouge).



Montage du siège.

 Placer le siège à son emplacement puis utiliser une vis de 4*12mm pour fixer le siège au corps de la voiture. Note! 1.when changing the tap position, please make sure the vehicle has completely stopped, otherwise it will demage the gear box and motor.



power switch, forward/backward switch are on the tank, pedal switch is on the right.

Power switch: Press the power switch to open, it will turn off if press again

Pedal switch Forward


- 1. Press the forward button
- 2. Tread the pedal, the car will move forward

Backward

- 1. Press the backward button
- 2. Tread the pedal, the car will move backward

Music Press the music botton, music will be played. If there is no more press, music will stop automatically


Mp3 Turn on the power botton, inserting Mp3/Mp4 wire into Mp3 slot, then adjusting the volume adjuster as you like.






Do not be close to the ear, improper use can cause hearing damage!!!

Charge the vehicle







- 1. Plug the charger port into the input socket.
- 2. Plug the charger plug into a wall outler, the battery will begin charging.

Caring For Your Vehicle


- Vehicle body is molded by polypropylene. Solarize or in -15'c use are strictly prohibited. Vehicles should be far away from a hot objects, like an oven and heater, plastic parts may melt beside.
- Avoid operating the vehicle in wet or snowy conditions. Do not wash the vehicle
 with soap and water. Water or moisture in the motors or electrical switches can
 cause them to corrode and could cause switch or motor failure.
- Avoid operating the vehicle on sand, loose dirt or gravel. Sand, loose dirt or gravel
 in the motors or electrical switches can case them to jam, and could cause switch
 or motor failure.
- The vehicle can be wiped down with a soft, dry cloth for a shiny finish, you can
 wipe plastic parts with a non-wax furniture polish applied to a soft-cloth. Do not
 use automotive wax. Do not use soap and water or spray the vehicle with a hose.
- Do not modify the electric system. When the fault appears and they must be maintained by professional. Alterations could cause a fire resulting in serious injury and could also ruin the electrical system.
- Use for about half month, check the wheels turning agilely or not, motor work is normal or not. Also infuse lube to lubricate moving parts.

Problems And Solutions Guide

Question 1: vehicle does not run

Reason: battery lack of electricity
 After riding each time, please recharge it timely. Must recharge it one time one month at least. Please charge 8-12 hours, but not more than 18 hours.

Reason: overload or improper use vehicle, fuse will turn off automatically.
 Appear this situation, please wait for about 2 minutes, do not use the vehicle, the fuse will turn on automatically again. The fuse of the vehicle is installed below the seat. (show as picture)



- Reason: battery is bad
 Please contact with the agent or manufacturer.
- Reason: the wires of vehicle are damage
 Please contact with the agent or manufacturer.
- Reason: motor is damage
 Motor need repair by professonals, please contact with the agent or manufacturer.

Question 2: battery can not recharge

- Reason: battery plug-in is loose
 Make sure the terminal of battery must be connected with the wires together.
- Reason: charger do not insert in right position
 Make sure the charger plug into a wall outlet. (if the outlet have open/off switch, please open the switch.)
- Reason: the charger does not work
 Whether the charger has a little hot when it is recharging? If not, maybe the charger is damage. Please contact with the agent or manufacturer.


Question 3: vehicle driving time is shorter

Reason: battery charge time is shortage
 Battery charge time is shortage or after use each time, please recharge it timely. Must recharge one time one month at least. Please charge 8-12 hours, but not more than 18 hours.



- Do not throw into a fire. The battery may explore or leak.
- Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.
- Return an exhausted battery to your local approved lead-acid battery recycle.





- 1. The product is not a transport, do not drive on the street, using the product under adult's guardianship.
- 2. Do not allow children under 36 months use the product.
- 3. Overage and overload are forbidden. Maximum load: 25KG.
- 4. The car should be assembled and che cked by adults, guarantee safety before using.
- 5. Do not wash the product with water, wiping the car using a soft wet cloth only.
- 6. Battery charging should be handled by adult only, the charging is not toy, do not let children play the charger.
- 7. Driving on public avenue, street, slope, pool side, stair head and other danger area are strictly forbidden.
- 8. Do not use this product in high-voltage line, trandfprmer station, gas station, hospital.
- 9. Please read carefully and keep this manual book for your children's safety.
- 10. In order to prevent a child from suffocation, keep plastic bags away ftom children.